



GUIDE DE POSE DES RADIATEURS
PLAATSINGSWIJZE VAN DE RADIATOREN
FITTING INSTRUCTIONS
ISTRUZIONI PER L'INSTALLAZIONE DEI RADIATORI
GUIA DE INSTALACION DE RADIADORES
BEFESTIGUNGSHINWEISE HEIZKÖRPER

DESIGNATION	L	H ±2,5	A	B	C	D
TAQ-050-052	518	580	90	318	360	60
TAQ-075-060	598	580	90	398	360	60
TAQ-100-076	757	580	90	557	360	60
TAQ-125-084	836	580	90	636	360	60
TAQ-150-100	995	580	170	636	360	60
TAQ-200-123	1234	580	170	875	360	60



